

4 PORT INTERNAL (FIXED VOLUME) INJECTOR P TYPE VALVES, ALL SERIES

SCHEMATIC FLOW DIAGRAM - 2 POSITION SWITCHING VALVE

Technical Note 301

All VICI Valco valves must be properly supported during tightening or loosening of fittings. This is best effected by the use of one wrench to support the valve body while another wrench tightens or loosens the nut.

NEVER use the valve shaft as a lever while tightening or loosening nuts.

FIGURE 1: Valve viewed from handle end

Standard sample sizes: 0.2, 0.5, 1.0, 2.0, 3.0, 4.0, and 5.0 μ l

